

EagleEye 1080P Dash Cam Quick Start Guide



DESCRIPTION OF BUTTONS

Description of Function Keys:

1) UP 2) Menu 3) DOWN 4) USB Port 5) HDMI Slot 6) Power 7) TF/Memory card Slot 8) Lock (SOS) 9) Mode 10) OK 11) IR LED Light 12) Speaker 13) Reset

SETTING DATE & TIME

1. Make sure camera is in “Standby Mode” (On video screen but not recording)
2. Short press “Menu” button twice
3. Short press “Down” 1 time or until “Date/Time” is highlighted
4. Short press “OK” button
5. Short press “UP” or “DOWN” to change year if needed
6. Short press “OK” to switch to next field (Repeat step 5 and 6 to change other categories)



Viewing Videos & Pictures

1. Make sure camera is in "Standby Mode" (On video screen but not recording)
2. Short press "Mode" button this will put your camera into photo mode (The symbol in the upper left hand corner should change from a white video camera to a white still frame camera)
3. Short press "Mode" again and camera will switch into play back mode (The symbol in the upper left hand corner should change to a square with smaller squares inside it)
4. Short press the "UP" or "DOWN" button to scroll through videos and pictures
5. Short press "OK" button to play videos
6. Short Press "Menu" button to delete videos and pictures

Emergency Record (S.O.S. Recording)

1. Make sure camera is in record mode
2. While camera is recording short press "Lock (SOS)" button (A lock should appear in the upper left hand corner of the screen)
3. The camera has now locked the video and the only way to erase the video is by formatting the memory card

Move Detect (Motion Detect)

1. Make sure camera is in "Standby Mode" (On video screen but not recording)
2. Short press "Menu" button to enter menu
3. Short press "DOWN" button 4 times or until "Motion Detect" is highlighted
4. Short press "OK" button to open menu option
5. Select and highlight which option you would like the setting to be on
6. Short press the "OK" button to confirm selection
7. Short press "Menu" button to exit menu