

ELECTRICAL INSTALLATION

- Cut the BLACK (-) ground wire and the fused RED (+) wire coming from the CB unit about 3½ inches past the fuse.
- 2. Cut the BLACK and RED wires coming from the Slide Mount BOTTOM HALF about 3½ inches from the Slide Mount.
- 3. Strip about ½ inch of insulation from the four ends.
- 4. Splice the BLACK wires together and tape securely.
- 5. Splice the RED wires together and tape securely.
- 6. If an external speaker is used, connect the WHITE and BLUE wires from the Slide Mount BOTTOM HALF to a miniature jack plug (not supplied) and plug into the external speaker receptacle on the back of the CB unit. If an external speaker is not used, tuck the wires carefully away.

- 7. Strip about ½ inch of insulation from the BLACK and the RED wire coming from the TOP HALF of Slide Mount.
- 8. Connect the BLACK wire of the TOP HALF of the Slide Mount to the car chassis ground.
- Splice and tape the RED wire of the TOP HALF of the Slide Mount to any fused hot line in the car.
- 10. The BLUE and WHITE wires from the Slide Mount TOP HALF are to be connected to an external speaker. If an external speaker is not used, tuck the wires carefully away.

REMEMBER TO DISCONNECT CB ANTENNA BEFORE REMOVING UNIT