	FUNC	ROGER BEEP	NB/ANL	DUAL WATCH
FUNC	FUNC OFF	BUTTON BEEP	BUTTON LOCK	LCD OFF
	SCAN	+10KHz	SWR METER	EMG CHANNEL
FUNC	SCAN LIST	HI-CUT TONE	TOT (TX Timer)	S/RF METER

LCD DISPLAY

CHANNEL DISPLAY

TRANSMIT RECEIVE INDICATOR

FUNC = FUNCTION

WHEN FUNC IS LIT ON THE LCD DISPLAY THE NAMES JUST UNDER THE 8 BUTTONS ARE ACTIVE.

TO PERFORM A MEMORY MASTER RESET:

PRESS AND HOLD THE FUNC & SCAN BUTTONS WHILE TURNING THE RADIO ON.

ALL FUNCTIONS WILL BE RESTORED TO FACTORY DEFAULT SETTINGS.

SQUELCH

VOLUME

ECHO DELAY

ECHO VOLUME

TX RF POWER

RX RF GAIN

BAND SWITCH 6 BANDS

MODE SWITCH

CLARIFIER & PUSH SELECTOR SWITCH

CHANNEL SELECTOR